


WHAT TO DO IF YOUR LUMKANI FIRE ALARM RINGS


ubiph omde – umlilo ekhayeni lakho

ONE LONG BEEEEEEEEEEEP
– Fire in your home




biph biph biph- umlilo ebumelwaneni

SHORT BEEP BEEP BEEP
– Fire in your neighbourhood




HOW TO INSTALL YOUR LUMKANI DEVICE CORRECTLY

DO'S



DONT'S



Call the Fire Department on 112 free from your cellphone if you see a fire

Watch DVD for full information

Contact Lumkani

SMS/WhatsApp/Call: 063 109 5401

www.facebook.com/Lumkani

www.lumkani.com

PUT THIS POSTER ON YOUR WALL



LUMKANI
PROTECTING AGAINST FIRES

Product Information

Lumkani Product Information

Please watch the DVD for more information about the Lumkani device. This page will show you how to install the device and how it works. The pictures will help you understand the information. We are stronger together than we are apart!

WARNING: Your Lumkani device does not stop fires. The Lumkani fire detector is an early warning system, giving you and your community the chance to act quickly to deal with a fire situation. If you are hearing impaired, the device may not be loud enough to alert you. Keep a bucket of sand or water ready in the event of a fire in your home or neighbourhood.

If there is a fire in your home or your community, take immediate action, you can make a **FREE CALL to the fire department by dialing 112** from your cell phone.

1 Use screws or nails to secure the device **flat against the wall**. Place the device on the wall as **high as you can reach** but ensuring you **can easily reach the button** of the device to silence it in case of false alarms and to test the battery. Place your device **one meter away from your cooking area and kettle**. Your Lumkani device is **NOT** waterproof so install the device in a **dry place with no leaks**. For large homes consider purchasing more than once device to cover your whole home. The device **does not ring** when there is smoke because it is a **heat detector and will only ring if the temperature of the room increases rapidly**. It will not ring when you cook.

2 All Lumkani devices are **connected** to each other and together they form a network. If your neighbour has a Lumkani device and a fire starts in their home, **their device will send a message to your device telling it to ring**. Each device in the community will pass the message on to the next until the whole community is alerted to the fire and can respond to the situation.

3 If the device rings in your home with **ONE LONG BEEEEEEP** sound, it means there is a fire in your home and you must wake your family and leave your home immediately. If there is no fire in your home but the device is ringing with **ONE LONG BEEEEEEP**, press the button on the front of the device to stop the ringing. **If you do not silence the alarm, all the devices in your neighbourhood will ring because they are connected in a network**. Make sure you can reach the button when you install the device.


4 If the device is ringing with a **SHORT BEEP BEEP BEEP** sound it means that there is fire in your community and you must be prepared to wake your family and leave your home. **First ask your neighbours** to see if there is a real danger.

5 To check the device is still working, **push and hold the button on the front of the device for 5 seconds**, the light will go on and the device will BEEP once. This means the device is working and the battery is healthy. Test your device **once per week** to make sure it's working.


6 If the **red light STAYS ON** or **STOPS flashing**, it means that your **battery is flat** and you must change it. To change the battery, remove the small screw on the front of the device and remove the old battery. The device will not work if the battery is flat.

For any questions or device problems you can call, SMS or WhatsApp us on **063 109 5401** and we will respond to you. Visit us on Facebook or our website www.lumkani.com - we are happy to help you!


- 1** **Sebenzisa izikhonkwane ukuxhoma isixhobo**
Use screws/nails to place device on wall




- 1** **Sukubeka isixhobo sakho entla kwesitovu**
Do not put your device directly above your stove




- Sixhome phezu kodwa ukwazi ukufikelela kwiqosha**
Place as high as possible within reach of the button



- 3** **ubiph omde – umlilo ekhayeni lakho**
Long Beep – Fire in your home



- 4** **biph biph biph- umlilo ebumelwaneni**
Beep Beep Beep – Fire in your community



Inkcukacha ngesixhobo iLumkani

Sicela ubukele le DVD echaza lukhulu ngesixhobo sika Lumkani. Eli phepha liza kukubonisa ukuba ungasifaka njani esi sixhobo kwaye, sisebenza njani. Imizobo izakunceda ukwazi ukuqonda ezincukacha. Somelele xa sikunye kuna xa sohlukene!

ISILUMKISO: Isixhobo sakho sikaLumkani asinqandi mli. Esisixhobo somlilo sisazisi mlibo kwangethuba, sinika wena nabahlali ithuba lokuba nizame ukujongana nomlilo ngokukhawuleza. Ukuba awuvi kakuhle ngendlebe, esisixhobo singanga ngxoli kakhulu side sikulumkise. Gcina ibhakethi lesanti okanye lamanzi ukulungiselela ukuba kungavala umlilo ekhayeni lakho okanye ekuhlaleni.

Ukuba kukho umlilo kwikhaya lakho okanye ekuhlaleni, thabatha amanyathelo ngokukhawuleza, **ufowunela kwisebe lezicima mli mahala kwiselifoni yakho ngokuthi ucofe u112.**

1 Sebenzisa izikhonkwane ukubethelela nokuqinisa **isixhobo eludongeni**. Sibeke **phezu-lu apho kodwa uqinisekise ukuba ungfikelela kweliqosha** eliphambili kwesixhobo sakho elenzela ukusithulisa xa sithe sakhala ngempazamo, nokwenzela ukuvavanya ibhetri. Beka esisixhobo malunga **nemitha enye kwindawo ophekela kuyo ne ketile**. Esisixhobo **ASIKHU-SELEKANGA EMANZINI** ngoko ke lendawo uzakusibeka kuyo **kufuneka yome ingabinamathontsi**. Kumakhaya amakhulu ingabubuchule ukuthenga izixhobo ezibini ukufikelela kwikhaya lonke. Esisixhobo **asikhali xa kungekho msi kuba sithatha ubushushu ngoko sakukhala xa iqondo lobushushu linyuka ngokukhawuleza**. Asizukukhala xa upheka.

2 Zonke izixhobo zikaLumkani **ziquhaqamshelelene**, xa zizonke zenza ikhonco. Ukuba umelwane wakho unesixhobo seLumkani, kuze kuqale umlilo kwikhaya lakhe, **isixhobo sakhe sizakuthumela umyalezo kwesakho isixhobo sisiyalela ukuba masikhale**. Isixhobo ngasinye ekuhlaleni sizakugqithisa lomyalezo kude kube wonke umntu ekuhlaleni, uvile ukuba kukho umlilo baze bakwazi ukwenza inzame zokunceda kulomeko.

3 Ukuba isixhobo sikhala kwikhaya lakho ngesandi **esiyi-biph ende** lonto ithetha ukuba kukho umlilo ekhayeni lakho. Usapho lwakho kufuneka luvuke lushiye ikhaya elo ngokukhawuleza. Ukuba akukho umlilo ekhayeni lakho kodwa isixhobo sikhala ngesandi **esiyi-bhip ende**, kufuneka ucofe iqhosha eliphambili ukusithulisa. **Ukuba awusithulisi, zonke izixhobo ekuhlaleni zizakukhala kuba ziyalelwe sisixhobo sakho kuba zidibene**. Xa usifakela isixhobo sakho qinisekisa ukuba uyakwazi ukufikelela kweliqosha liphambili.

4 Ukuba isixhobo senza ingxolo ethi biph, biph, biph lonto ithetha ukuba kukho umlilo ekuhlaleni kwaye kufuneka ulungiselele ukuvusa usapho lwakho nilishiye ikhaya lenu. Kuqala buza abamelwane ukuba ukuba ingaba kukho ingozi ngokwenene.

5 Ukujonga ukuba isixhobo siyasebenza, **cofa eliqhosha liphambili okomzuzwana**, iza kulayita isixhobo sizakwenza ingxolo **ethi biph**. Lonto ithetha ukuba isixhobo siyasebenza kwaye nabattery isaphilile. Vavanya isixhobo sakho **kanye ngeveki** ukuqinisekisa ukuba siyasebenza.

6 Ukuba ilayita **bomvu endaweni yokudanyaza okanye icimile lonto** ithetha ukuba **ibhetri yakho iflethi** kwaye kufuneka uyitshintshise. Ukutshintsha ibhetri khulula isikhonkwane sakho esingaphambili kwisixhobo sakho ukhuphe labhetri indala. Isixhobo sakho asizukusebenza ukuba ibhetri iflethi.

Ukuba unemibuzo okanye ingxaki ngesixhobo sakho, ungasifowunela umnxeba okanye uthumele umyalezo, WhatsApp kulombolo **063 109 5401** sizakuku phendula. Sindwendwele naku Facebook okanye kwi (site) yethu, nakwi (web) www.lumkani.com sovuyiswa kukunceda!